



DIAMOND / SEA-GLAZE

Window Template Instructions

1. **Create a Plan View of the boat showing window locations and give each template a number for referencing.**
2. Ensure that window opening is clean and free from all sealants, etc. that could distort true shape of opening.
3. Attach paper or cardboard to outside or inside of vessel depending on which side will be easier to get an accurate tracing of opening.
4. Trace opening with fine tipped pen making sure to get lines as accurate as possible.
5. Label template **TOP** and whether it is “**inside view**” or “**outside view**”
6. Label template as **Port** or **Starboard- Forward** or **Aft**.
7. On sliding windows indicate sliding panel. “**X**” indicates sliding and “**O**” indicates fixed panel. Indicate if a screen is required. Sliding windows must be parallel. Indicate if T-bar is to be vertical or sloped to match forward or aft angle.
8. For vent windows-indicate where the split should be by measuring the distance from the bottom of the cut-out to the top of the division bar. Label vent with “**X**”.
9. Other information we require on templates:
 - **Indicate window type-** Such as D15, D5, 106S (see catalogue or website)
 - **Finish-**Clear anodized, powder coat or Awl Grip. (specify color)
 - **Corners-** Radius 2 ½”, 3”, 3 ½”or Mitered.
 - **Glass thickness-**1/4”, 3/8”, ½”, 5/8” ¾” or Double Glazed.
 - **Glazing type-** Tempered, Laminated, or Lexan
 - **Glass tint-** Bronze, green, grey or clear.
 - Clamp-in or bolt-on installation.
 - Finished wall thickness for interior trim ring. (Clamp-in style)
10. Roll up paper templates (do not fold cardboard) and Ship to:

Diamond Sea Glaze Manufacturing Ltd.

26995 Gloucester Way

Langley, BC Canada, V4W 3Y3

www.diamondseaglaze.com

